

NOTES:

- 1. OPERATION
 - 1. GENTLY LIFT LATCH AT SIDE OF CONNECTOR.
 - 2. SWING COVER OFF OF CONTACTS.
 - 3. SLIDE THE FLEX TAPE INTO THE CONNECTOR PLACING THE EDGE OF THE FLEX TAPE UNDER 2 HOLD DOWN TABS.
 - 4. FOLD OVER THE COVER AND PRESS IN PLACE UNTIL THE LATCH IS FULLY ENGAGED.
- 2. LIMIT CURRENT TO A MAXIMUM OF 5 AMPS.

JKL PART NO.: ZCH-137HD-8J

			METRIC	DIMENSIONS ARE IN mm (INCHES) TOLERANCE UNLESS OTHERWISE SPECIFIED		JKL COMPONENTS CORPORATION					
			THIRD ANGLE PROJECTION	1 PL +/ 2 PL +/ ANGLE +/	- REF. - REF.	TITLE		OLDER 8mm ER CONNEC	FLEX TAPE TOR		
		8/20/15 10/10/14	DRAWN BY L. WENGSTROM	APPV'D BY L.R.	DATE 8/20/15		55335	NO.	ZCH-137HD)-8J	
REV. N∩		APPV'D DATE	- CAD DRAWING - MANUAL REVISIONS NOT PERMITTED			SCALE		DATE 10/10/14	REVISION BATE 8/20/15	NO. A	SHEET 1 OF 1